

Only Cement

CLAY CEMENT

APPLICATION METHOD

SUBSTRATES:

- Substrates must be dry, solid, and free of dust, paint, wax, oil, loose particles, and seasoned surfaces.

APPLICATION:

1. Apply a single coat of Primer NK evenly over the entire surface using a roller.
2. Let dry for 24 hours (+20°C).
3. Apply the first coat of Cemento 3D using a stainless-steel trowel.
4. Let dry for 12 hours (+20°C).
5. Apply a second coat of Cemento 3D over approximately 4-6 m², then go back and smooth the wet product by tilting the stainless-steel trowel until smooth and uniform.
6. Let dry for 24 hours (+20°C).
7. Apply a single coat of Cream Wax over the entire surface using a stainless-steel trowel.
8. Let dry for 12 hours (+20°C).
9. Polish the surface using an electric polisher with the appropriate soft wool pad.