

CEMENT METAL

APPLICATION METHOD

SUBSTRATES:

Substrates must be dry, solid, and free of dust, paint, wax, oil, loose particles, and seasoned surfaces.

WALL APPLICATION:

- 1. Apply a single coat of Primer NK evenly over the entire surface using a roller.
- 2. Let dry for 24 hours (+20°C).
- 3. Apply a single coat of Cemento 3D over 2-3 m² using a stainless-steel trowel. Use a doormat pad to draw the desired texture over the still-wet product. Before the product dries, gently smooth the surface using a stainless-steel trowel, taking care to flatten only the protruding parts.
- 4. Let dry for 24 hours (+20°C).
- 5. Apply a single coat of Decor Fix using a brush, following the previously created texture. Immediately afterward, spread the Daranà© foil over the still-wet Decor Fix, overlapping the foils by 1 cm. Proceed in this manner over the entire surface to be decorated.
- 6. Let dry for 2 hours (+20°C).
- 7. Remove the foil from the surface and apply a single layer of ProteKto EcoSilan using a brush, taking care to follow the previously created texture.
- 8. Let the product rest for about 15 minutes and gently clean the surface using a soft cotton cloth.